

#### Exterior







<sup>\*:</sup> If equipped

<sup>\*1:</sup> For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".


### Interior





\*: If equipped


В





#### Automatic transmission

Automatic transmission shift lever P. 146



Seat heater switches \* P.345

Seat heater/ventilator switches \* P.348

Shift lock override button P. 503


Cigarette lighter \* P. 343

Ashtray \* P. 342

Auxiliary box \* P. 335

#### ► Manual transmission

Manual transmission shift lever P.152



Parking brake lever P. 155

Seat heater switches \* P. 345

Seat heater/ventilator switches \* P.348


Cigarette lighter \* P.343

Ashtray \* P. 342

Auxiliary box \* P. 335


\*: If equipped

#### Instrument panel



## Α

#### ► Without navigation system





\*: If equipped

# Instrument panel



#### ▶ With navigation system







<sup>\*:</sup> If equipped
\*1: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".
\*2: Refer to "Navigation System Owner's Manual".

# Instrument panel

